

Audible/Visible Indicators

ACTION	AUDIBLE INDICATOR		VISIBLE INDICATOR
	without Thermistor	with Thermistor	
Automatic Activation (with air cylinder pressure applied)	Redundant Alarm Startup — Single Rising Tone with Bee-Bop	Redundant Alarm Startup — Single Rising Tone with Bee-Bop	GREEN/YELLOW Lights Flash Front Panel
Manual Activation	Redundant Alarm Startup — Single Rising Tone with Bee-Bop (also Full Alarm)	Redundant Alarm Startup — Single Rising Tone with Bee-Bop (also Full Alarm)	YELLOW/RED Lights Flash Front Panel
Sensor Mode (with or without Pressure)	none	none	GREEN Light Flashes
PreAlarm (with or without Pressure)	First 4 seconds (approximate)	Low Volume Rising Tone	RED Light Flashes
	Second 4 seconds (approximate)	Medium Volume Buzz	
	Last 4 seconds (approximate)	High Volume Rise Tone Followed by Buzz	
Full Alarm (with or without Pressure)	Two High Volume Tones Followed by Buzz	Two High Volume Tones Followed by Buzz	RED Light Flashes
Deactivation of Full Alarm	1st push of reset button	Bee	RED Light Flashes
	2nd push of reset button	Bee-Bop-Bop	GREEN Light Flashes
Deactivation of PreAlarm (with Shake or move Unit Pressure)	none	none	GREEN Light Flashes
Low Battery	1 Beep every 5 seconds	1 Beep every 5 seconds	none
Thermal Alarm Activation (see Thermal Alarm Activation Curve)	N/A	1 Beep every 3 seconds	none
Redundant Alarm			
Low-Pressure Alarm	Bee Bee	Bee Bee	Yellow Light Flashes Green Light Flashes Gauge Light Flashes